

NYX-14

Multi-Purpose Night Vision Monocular

The Armasight Nyx-14 is the new standard by which all compact multiuse monoculars will be judged in the future. The Nyx-14 uses optics that are equal to or better than current Military issue Night Vision units, built into a tough, compact, and ergonomic composite housing. Armasight designed and built this unit to surpass MIL-SPEC-810 specifications – as a result, the Armasight Nyx-14 can withstand saltwater, rain, high humidity, and temperature extremes, and still provide unsurpassed levels of performance.

The Nyx-14 mini-monocular is equipped with manual variable gain control so that the user can select the image brightness level, in order to properly adjust for ambient light levels in the environment. The Armasight Nyx-14 is available with an array of accessories such as 3X, 5X, and 8X magnification lenses for mid-to-long range viewing; head or helmet mounts to allow the unit to be worn as a mono-goggle; various weapon mounts for tactical or hunting applications; and additional, high-powered IR illuminators for long-range use. The Armasight NYX-14 can be equipped with high-performance Gen 2+ and Gen 3 IITs including Green phosphor or Armasight's "Quick Silver" and "Ghost" IITs, which provide users with natural B&W Night Vision displays. The Armasight NYX-14 is a high-standard Night Vision device that will meet the requirements of the most demanding law enforcement officer, military professional, or casual civilian user.

- Compact, rugged design
- Manual Gain Control
- Water and Fog-Resistant / Waterproof (optional)
- Mead or helmet-mountable for hands-free usage
- **Meapon-mountable**
- Bright light cut-off
- Ergonomic, simple, easy to operate controls
- O Utilizes single CR123A lithium or AA battery
- Adaptable for use with cameras
- Built-in Infrared illuminator and flood lens
- A Limited two-year warranty













SPECIFICATIONS

IIT Generation	Gen 2+ SD - "Standard Definition" 45-51 lp/mm Gen 2+ ID - "Improved Definition" 47-54 lp/mm Gen 2+ HD - "High Definition" 55-72 lp/mm Gen 2+ QS - "Quick Silver" White Phosphor 47-54 lp/mm Gen 3 Bravo - 57 lp/mm (min) - 64 lp/mm (typical) Gen 3 Alpha - High Performance 64-72 lp/mm Gen 3 Ghost - "Ghost" White Phosphor 47-57 lp/mm Gen 3 P - High Performance ITT 64-72 lp/mm PINNACLE® I FLAG - Filmless Auto-Gated IIT (comparable to Gen 4) 64-72 lp/mm
Magnification	1x standard (3x, 5x, 8x optional)
Lens System	F/1.2; 27 mm
Field of View	40°
Focus Range	0.25m to infinity
Exit Pupil Diameter	14 mm
Eye Relief	25 mm
Diopter Adjustment	-6 to +2 dpt
Manual Gain Control	Yes
Bright Light Cut-off	Yes // // // // // // // // // // // // //
Automatic Shut-off System	Yes
Infrared Illuminator	Yes (built-in with pivotal flood lens)
IR Indicator	Yes (in FOV)
Low Battery Indicator	Yes (in FOV)
Power Supply	CR123 Lithium 3V (1), or AA Alkaline 1.5V (1), or any AA or CR123 type rechargeable batteries with voltage from 1.2V to 3.7V (1)
Battery Life	Up to 60 hours
Environmental Rating	Water and Fog-Resistant / Waterproof (optional)
MIL-STD-810	Yes
Operating Temperature	-40° to +50°C (-40° to +122°F)
Storage Temperature	-50° to +70°C (-58° to +158°F)
Overall Dimensions	120 x 49 x 69 mm (4.7 x 1.9 x 2.7 in)
Weight	0.4 kg (0.88 lbs)
Warranty	2 Years

^{*} All data subject to change without notice.





Part No. ANHG000002



Part No. ANHM000172



Part No. ANHMWX0G05















Part No. ANECO00001 SHUTTER EYEGUARD #82



DEMIST SHIELD #34





XLR-IR850 DETACHABLE IR ILLUMINATOR







ONE BATTERY



BATTERY ADAPTER



OPTIONAL EQUIPMENT



Part No. ANAF3X0002 3X A-FOCAL LENS



Part No. ANAF5X0002 5X A-FOCAL LENS





Part No. ANAMRF0003







Part No. ANHM000001



Part No. ANHM000007



Part No. ANHM000008

Part No. ANKI000049



Part No. ANAM000006







SACRIFICIAL WINDOW #30





